




4 Dimensions (in/mm)



5 Current sensors



6



QUICK START GUIDE

EN

socomec
Innovative Power Solutions




Power Monitoring System for electrical installations


DIRIS Digiware



Socomec Resource Center
To download, brochures, catalogues
and technical manuals





1 System wiring – exploded view





Main network connections and loads
DIRIS Digiware I-3x

Each current input setting is individual, see below some examples:




Main network connections and loads
DIRIS Digiware I-4x

Each current input setting is individual, see below some examples:



Main network connections and loads
DIRIS Digiware I-6x

Each current input setting is individual, see below some examples:



3 Configuration

